

2019 Water Quality Report

GLENDORA SYSTEM

This report reflects water quality testing conducted during 201


A Word of Assurance about

Your 2019 Water Quality Report

our drinking water is constantly monitored from source to tap for regulated and unregulated constituents through comprehensive drinking water quality compliance testing programs carried out by dedicated Suburban Water Systems (Suburban) professionals.

Certified quality assurance professionals collect hundreds of water samples each year to safeguard the quality of your tap water. These samples are analyzed in the field at the time of sample collection or by independent, state-certified laboratories for various substances as mandated by law. The results of these samples are then electronically submitted to the State Water Board (SWB), which oversees water quality compliance for all public water systems in California. The Covina Irrigating Company (CIC), a wholesale supplier to Suburban, has its own comprehensive drinking water source and treatment monitoring programs that comply with United States Environmental Protection Agency (USEPA) and California regulatory requirements.





For more than 60 years, Suburban has provided dependable, high-quality water that complies with all federal and state health safety standards to thousands of families in the San Gabriel Valley and nearby areas. We are proud to report that 2019 was no exception.

Who We Serve

Suburban provides drinking water to the portion of Glendora bounded on the north and south by the Santa Fe Railroad and Arrow Highway, respectively, and on the east and west by Grand Avenue and Barranca Avenue, respectively. Suburban serves approximately 6,500 people. In 2019, Suburban's water supply was purchased from the CIC. CIC filters and disinfects local surface water from the San Gabriel mountains. If needed, Suburban can purchase local groundwater from the City of Glendora.


Suburban's Drinking Water Complies with All Health and Safety Regulations

In order to ensure that tap water is safe to drink, the USEPA and the SWB prescribe regulations that limit the amount of certain contaminants in water provided by public water systems. SWB regulations also establish limits for contaminants in bottled water, which must provide the same protection for public health. Last year, as in the past, Suburban's drinking water was in full compliance with all applicable

county, state and federal drinking water regulations. Our system of pumps, reservoirs and
 distribution pipelines are all routinely inspected, monitored and maintained by professional
 state-certified water system operators to protect the quality of the water from source to tap.







You can determine how the water quality in your area compares to government standards by finding the average values in the charts and comparing these values to the maximum contaminant level (MCL).

> Chemicals reported in the table were detected in the water by independent accredited laboratories during 2019 or from the most recent tests. Most, but not

all, of these chemicals are minerals, metals, and radiologicals occurring naturally in the water. Some of these chemicals, however, are the result of 1) drinking water treatment processes — chlorine residual, disinfection byproducts, aluminum; 2) agricultural practices that occurred many decades ago — nitrate; and 3) household plumbing — copper.

To help you understand what these test results mean, we have also included information about significant constituents, measurements, water quality definitions and advisories.



Purpose

of this

Report

Are There Risks?

Drinking water, including bottled water, may reasonably be expected to contain at least small amounts of some contaminants. The presence of contaminants does not necessarily indicate that water poses a health risk.

More information about contaminants and potential health effects can be obtained by calling the USEPA's Safe Drinking Water Hotline (800) 426-4791.

Some people may be more vulnerable to contaminants in drinking water than the general population.

Immuno-compromised persons such as persons with cancer undergoing chemotherapy, persons who have undergone organ transplants, people with HIV/AIDS or other immune system disorders, some elderly, and infants can be particularly at risk from infections. These people should seek advice about drinking water from their health care providers.

USEPA/Centers for Disease Control (CDC)

guidelines on appropriate means to lessen the risk of infection by *Cryptosporidium* and other microbial contaminants are available from the Safe Drinking Water Hotline (800) 426-4791.





Household Issues that May Affect You or Your Water Quality...

• Hot Water Heaters: Many odor complaints may be traced to

- the home's hot water heater. Remember to follow manu-
- facturer's instructions and flush hot water heaters regularly.
- This will flush out any sediments that may have
- accumulated, provide good water turnover to maximize
- water quality, and help keep your unit in good working order.
- Point of Use or Home Water Filtration Units: Be vigilant in
- changing or cleaning any filters or media on your home units.
- Always follow the manufacturers instructions. Remember,
- the water is only as clean as the filter allows. Improperly
- maintained filters can deliver very poor quality water.





Contaminants that May Be in the Water

The sources of drinking water (both tap water and bottled water) include rivers, lakes, streams, ponds, reservoirs, springs and wells. As water travels over the surface of the land or through the

Contaminants that may be present in source water include:



Microbial contaminants, such as viruses and bacteria that may come from sewage treatment plants, septic systems, agricultural livestock operations and wildlife.



Inorganic contaminants, such as salts and metals that can be naturally-occurring or result from urban storm water runoff, industrial or domestic wastewater discharges, oil and gas production, mining or farming.



Pesticides and herbicides, which may come from a variety of sources such as agriculture, urban storm water runoff, and residential uses.



Organic chemical contaminants, including synthetic and volatile organic chemicals that are byproducts of industrial processes and petroleum production, and can also come from gas stations, urban storm water runoff, agricultural application and septic systems.



Radioactive contaminants that can be naturally-occurring or be the result of oil and gas production and mining activities.



ground, it dissolves naturally-occurring minerals and, in some cases, radioactive material, and can pick up substances resulting from the presence of animals or from human activity.



Lead, if present in elevated levels, can cause serious health problems, especially for pregnant women and young children.

Lead in drinking water is primarily from materials and components associated with service lines and home plumbing. Suburban is responsible for providing highquality drinking water, but cannot control the variety of materials used in plumbing components.

> When your water has been sitting for several hours, you can minimize the potential for lead exposure by flushing your tap for 30 seconds to two minutes before using water for drinking or cooking.

If you are concerned about lead in your water, you may wish to have your water tested. Information on lead in drinking water, testing methods, and steps you can take to minimize exposure is available from the Safe Drinking Water Hotline (800) 426-4791 or at www.epa.gov/lead.

Chemical	Covina Met Standard?	rrigating Co Year Tested		ered San G Average	Range	MCL	Vater Proje PHG (MCLG)	Typical Source of Contaminant
Primary Standards								
Aluminum (ppm)	Yes	2019	ppm	0.06	ND - 0.1	1	0.6	Treatment Chemical Residue
Arsenic	Yes	2019	ppb	2	ND - 3	10	0.004	Runoff or Leaching from Natural Deposits
Fluoride	Yes	2019	ppm	0.2	0.2	2	1	Runoff or Leaching from Natural Deposits
Gross Alpha Radiation	Yes	2015	pCi/L	3	3	15	0	Erosion of Natural Deposits
Nitrate	Yes	2019	ppm-N	0.4	0.2 - 0.6	10	10	Fertilizers, Septic Tanks
Uranium	Yes	2015	pCi/L	2	2	20	0.43	Erosion of Natural Deposits
Secondary Standards*	-	·	·	•	•	•	•	
Aluminum (ppb)	Yes	2019	ppb	63	31 - 110	200*	600	Treatment Chemical Residue
Chloride	Yes	2019	ppm	40	37 - 44	500*	n/a	Runoff or Leaching from Natural Deposits
Odor	Yes	2019	TON	1	1	3*	n/a	Naturally-Occurring Organics
Specific Conductance	Yes	2019	µmho/cm	320	280 - 360	1,600*	n/a	Ions in Water; Seawater Influence
Sulfate	Yes	2019	ppm	23	15 - 31	500*	n/a	Runoff or Leaching from Natural Deposits
Total Dissolved Solids	Yes	2019	ppm	170	140 - 200	1,000*	n/a	Runoff or Leaching from Natural Deposits
Unregulated			1	1			•	
Alkalinity, total	n/a	2019	ppm CaCO3	84	82 - 86	n/r	n/a	Runoff or Leaching from Natural Deposits
Calcium	n/a	2019	ppm	20	15 - 25	n/r	n/a	Runoff or Leaching from Natural Deposits
Hardness, total	n/a	2019	ppm CaCO3	84	67 - 100	n/r	n/a	Runoff or Leaching from Natural Deposits
Hardness, total	n/a	2019	grains/gal	5	4 - 6	n/r	n/a	Runoff or Leaching from Natural Deposits
Magnesium	n/a	2019	ppm	8	7 - 9	n/r	n/a	Runoff or Leaching from Natural Deposits
рН	n/a	2019	pH units	8.0	8.0 - 8.1	n/r	n/a	Acidity, Hydrogen Ions
Potassium	n/a	2019	ppm	2	1 - 3	n/r	n/a	Runoff or Leaching from Natural Deposits
Sodium	n/a	2019	ppm	28	25 - 30	n/r	n/a	Runoff or Leaching from Natural Deposits
Total Organic Carbon (ppm)	Yes	2019	ppm	2	2 - 3	Treatment	Technique	Various Natural Decaying Sources
ppb = parts-per-billion; ppm = pa μ mho/cm = micromho per centim PHG = California Public Health Go	eter; < = average is	less than the det	ection limit for r	reporting purpos	ses; MCL = Max	imum Contamina	ant Level; (MC I	_G) = federal MCL Goal;
Turbidity - Combined Filter Effluent TT			Value	Met Standard?	Source	Turbidity is a n matter, some c	Furbidity is a measure of the cloudiness of the water, an indication of particulate natter, some of which might include harmful microorganisms. Low turbidity CIC's	
Covina Irrigating Company Ter	nple Filtration Plan	t		1			-	tor of effective filtration. Filtration is called a treatment
1) Highest single turbidity measurement 0.3		0.3	0.1	Yes	Run-Off	technique (TT). A treatment technique is a required process intended to reduce th level of contaminants in drinking water that are difficult and sometimes impossible		
2) Percentage of samples less than 0.3 NTU 95		95%	100	Yes	Run-Off	to measure directly.		

Chemical (Units)	Met Standard?	MCL (MRDL/MRDLG)	Average	Range	Typical Source of Contaminant
Disinfection Byproducts					
Total Trihalomethanes (ppb)	Yes	80	48	20 - 76	Byproducts of Chlorine Disinfection
Haloacetic Acids (ppb)	Yes	60	16	10 - 19	Byproducts of Chlorine Disinfection
Chlorine Residual (ppm)	Yes	(4 / 4)	2	0.01 - 3.0	Disinfectant Added for Treatment
Aesthetic Quality					
Color (Color Units)	Yes	15*	<3	ND - 5	Erosion of Natural Deposits
(,					
Turbidity (ntu)	Yes	5*	<0.1	ND - 0.6	Erosion of Natural Deposits
Turbidity (ntu) Odor (threshold odor number) Two locations in the distribution syst odor and turbidity. MRDL = Maximu turbidity units; ND = not detected; <	Yes em are tested quarterly for m Residual Disinfectant Lev = average is less than the d	3 [*] total trihalomethanes and /el; MRDLG = Maximum F etection limit for reporting	1 haloacetic acids; o Residual Disinfecta	1 - 2 ne location is tested we	Erosion of Natural Deposits ekly for color,
Turbidity (ntu) Odor (threshold odor number) Two locations in the distribution syst odor and turbidity. MRDL = Maximu turbidity units; ND = not detected; < *Contaminant is regulated by a seco	Yes em are tested quarterly for m Residual Disinfectant Lev = average is less than the d ondary standard to maintain	3* total trihalomethanes and /el; MRDLG = Maximum F etection limit for reporting aesthetic qualities.	1 haloacetic acids; o Residual Disinfecta purposes;	1 - 2 ne location is tested we nt Level Goal; ntu = ne	Erosion of Natural Deposits ekly for color, ohelometric
Turbidity (ntu) Odor (threshold odor number) Two locations in the distribution syst odor and turbidity. MRDL = Maximu turbidity units; ND = not detected; <	Yes em are tested quarterly for m Residual Disinfectant Lev = average is less than the d	3 [*] total trihalomethanes and /el; MRDLG = Maximum F etection limit for reporting	1 haloacetic acids; o Residual Disinfecta	1 - 2 ne location is tested we	Erosion of Natural Deposits ekly for color,
Turbidity (ntu) Odor (threshold odor number) Two locations in the distribution syst odor and turbidity. MRDL = Maximu turbidity units; ND = not detected; < *Contaminant is regulated by a seco	Yes em are tested quarterly for m Residual Disinfectant Lev = average is less than the d ondary standard to maintain	3* total trihalomethanes and /el; MRDLG = Maximum F etection limit for reporting aesthetic qualities.	1 haloacetic acids; o Residual Disinfecta purposes;	1 - 2 ne location is tested we nt Level Goal; ntu = ne	Erosion of Natural Deposits ekly for color, ohelometric Typical Source of Contaminant
Turbidity (ntu) Odor (threshold odor number) Two locations in the distribution syst odor and turbidity. MRDL = Maximu turbidity units; ND = not detected; < *Contaminant is regulated by a seco Bacterial Quality	Yes em are tested quarterly for m Residual Disinfectant Lev = average is less than the d ondary standard to maintain Met Standard?	3* total trihalomethanes and rel; MRDLG = Maximum F etection limit for reporting aesthetic qualities. <u>MCL</u> No more than 1 positive total coliform in	1 haloacetic acids; o Residual Disinfectar purposes; MCLG	1 - 2 ne location is tested we nt Level Goal; ntu = nep Number Positive	Erosion of Natural Deposits ekly for color, ohelometric
Turbidity (ntu) Odor (threshold odor number) Two locations in the distribution syst odor and turbidity. MRDL = Maximu turbidity units; ND = not detected; < : *Contaminant is regulated by a seco Bacterial Quality Total Coliform Bacteria	Yes em are tested quarterly for m Residual Disinfectant Lev = average is less than the d ondary standard to maintain Met Standard? Yes	3* total trihalomethanes and /el; MRDLG = Maximum P etection limit for reporting aesthetic qualities. MCL No more than 1 positive total coliform in a month	1 haloacetic acids; o Residual Disinfectar purposes; MCLG 0	1 - 2 ne location is tested we nt Level Goal; ntu = ne Number Positive 0	Erosion of Natural Deposits ekly for color, ohelometric Typical Source of Contaminant Bacteria that occur naturally in soils and water

Water Quality Goals

The water Suburban delivers to your home meets standards required by USEPA, SWB and California Public Utilities Commission (PUC). Often, Suburban goes beyond what is required to monitor for constituents that have known health risks. The company uses only independent, state-certified water quality laboratories for testing. The charts in this report include two types of water quality goals:

- Maximum Contaminant Level Goal (MCLG): The level of a contaminant in drinking water below which there is no known or expected risk to health.
 MCLGs are set by the USEPA.
- Public Health Goal (PHG): The level of a contaminant in drinking water below which there is no known or expected risk to health. PHGs are set by the California Environmental Protection Agency.

Water Quality Standards

The quality of drinking water in the United States is regulated by the USEPA. Two state agencies, the SWB and the PUC, supplement and enforce federal USEPA standards. Standards established by these agencies are used to set limits for substances that may affect health or aesthetic qualities of water. The water quality charts in this report cover the following standards:

- Maximum Contaminant Level (MCL): The highest level of a contaminant that is allowed in drinking water. Primary MCLs are set as close to the PHGs (or MCLGs) as is economically and technologically feasible. Secondary MCLs are set to protect the odor, taste and appearance of drinking water.
- Maximum Residual Disinfectant Level (MRDL): The highest level of a disinfectant allowed in drinking water. There is convincing evidence that addition of a disinfectant is necessary for control of microbial contaminants.
- Maximum Residual Disinfectant Level Goal (MRDLG): The level of a drinking water disinfectant below which there is no known or expected risk to health. MRDLGs do not reflect the benefits of the use of disinfectants to control microbial contaminants.
- Primary Drinking Water Standard (PDWS): MCLs and MRDLs for contaminants that affect health along with their monitoring and reporting requirements, as well as water treatment requirements.
- Regulatory Action Level (AL): The concentration of a contaminant which, if exceeded, triggers treatment or other requirements that a water system must follow.



Source Water and Water Quality Assessments

In 2019, Suburban distributed treated surface water from CIC and has the capability of distributing groundwater through an interconnection with the City of Glendora. CIC and Glendora have completed source water assessments in accordance with the federal Safe Drinking Water Act. The purpose of the source water assessment is to promote source water protection by identifying types of activities in the



proximity of sources which could pose a threat to the water quality. You may request summaries of the assessments by contacting Ken Reich, Quality Assurance Reporting Manager, at (626) 543-2575 or you may request complete copies from the SWB at (818) 551-2049.

City of Glendora source water assessments were completed in 2001 and concluded that Glendora's groundwater wells are considered most vulnerable to the following activities or facilities associated with contaminants detected in the water supply: crops irrigation, fertilizer, pesticide/herbicide application and known contaminant plumes. In addition, the groundwater wells are considered most vulnerable to the following facilities not associated with contaminants detected in



the water supply: utility stations maintenance areas, above ground storage tanks and high density of housing. Every five years, CIC is required to examine and update possible sources of drinking water contamination in their surface water source waters. These reports are called watershed sanitary surveys. CIC completed an update of its San Gabriel River watershed sanitary survey in 2015. The survey concluded that CIC's surface water is vulnerable to contamination from erosion, debris removal, forest fires and recreational activities.

Chloramines

CIC converts free chlorine to chloramines as its residual disinfectant. Chlorine and ammonia are combined at the CIC treatment facility to produce these chloramines. Chloramines are added to the water for public health protection because they prevent regrowth of bacteria in the distribution system pipes and also reduce the formation of certain chemicals that are regulated in drinking water. All of Suburban's water has some form of chlorine disinfectant residual at all times.

Be advised that kidney dialysis units and aquarium owners must remove chloramines from water prior to use. Hospitals or dialysis centers should be aware of the chloramines from water and should install proper chloramine removal equipment, such as carbon adsorption units. Aquarium owners can use readily available products to remove or neutralize chlorine.

Chloraminated water is safe for people and animals to drink, and for all other general uses.

Should you have any questions or concerns regarding chloramine in your water, please contact Ken Reich, Quality Assurance Reporting Manager at (626) 543-2575.



The Quality of Your Water Is Our Primary Concern



This report contains important information about your drinking water. Translate it, or speak with someone who understands it.								
ير على معلومات ــة مـاء الشرب في تىرجمته، أو ابحث يـق لك يفـهم هـذه	امـة عـن نـوعـي نطقتك يرجى ا	 ▲ 讲到关于您所 → 质。请您找人 」 请能看得懂这 	些重要的信息, 在社区的水的品 翻译一下,或者 份报告的朋友给	इस रिपोर्ट में पोने के पानी' के विषय पर बहुत जरूरी जानकारी दी गई है। कृपया इसका अनुवाद कीजिये, या किसी जानकार से इस बारे में पूछिये।				
Arabic		Chinese		Hindi				
についての大切な情報が書かれ 入 ています。内容をよく理解する 7 ために、日本語に翻訳して読む お		이 보고서에는 귀히 지역의 수질에 관한 가 들어 있습니다. 하거나 충분히 이히 와 상의하십시오.	한 중요한 정보 이것을 변역	Este reporte contiene información importante sobre su agua de beber. Tradúzcalo ó hable con alguien que lo entienda bien.				
Japanese	apanese K			Spanish				
	pag-inom ng ti	g mahalagang tungkol sa iyong ubig. Isalin ito, o sa isang tao na	Bản báo cáo có g tiết quan trọng vé nước trong cộng v Hãy nhờ người thạn hỏi một người bạn l để này.	ề phẩm chất dồng quý vị. ng dịch, hoặc				

Vietnamese

How to Read Your Water Meter

Your water meter is usually located between the sidewalk and curb under a cement cover. Remove the cover by inserting a screwdriver in the hole in the lid and then carefully lift the cover. The meter reads straight across, like the odometer on your car. Read only the black numbers (0895).

If you are trying to determine if you have a leak, turn off all the water in your home, both indoor and outdoor faucets, and then check the dial for any movement of the low-flow indicator. If there is movement, that indicates a leak between the meter and your plumbing system. Low-Flow Indicator ~ The low flow indicator will spin if any water is flowing through the meter.

Tagalog



- Sweep Hand ~ Each full revolution of the sweep hand indicates that one cubic foot of water (7.48 gallons) has passed through the meter. The markings at the outer edge of the dial indicate tenths and hundredths of one cubic foot.
- Other Register ~ The meter register is a lot like the odometer on your car. The numbers keep a running total of all the water that has passed through the meter. The register shown here indicates that 89,505 cubic feet of water has passed through this meter.

Public Participation Opportunities

We value your input, concerns and suggestions. Please contact Lauren James, Communications Manager, at (626) 543-2531 or email her at LJames@swwc.com to inquire about possible future public participation

opportunities. Also, please feel free to contact **Ken Reich**, **Quality Assurance Reporting Manager**, at (626) 543-2575, if you have any questions about water quality. In addition, a number of local water boards hold monthly meetings that are open to the public, including:

> Metropolitan Water District of Southern California Second Tuesday of the month, (213) 217-6000

Main San Gabriel Basin Watermaster First Wednesday of the month, (626) 815-1300

Upper San Gabriel Valley Municipal Water District First and third Tuesday of the month, (626) 443-2297



Suburban Water Systems

A SouthWest Water Company

District Office: San Jose Hills

2235 E. Garvey Avenue North, Suite A West Covina, California 91791

Customer Service: (626) 543-2640 sanjosehills@swwc.com

www.swwc.com/suburban